

7

Troubleshooting

Major faults with this chamber are detected through equipment self-checks. The details of the fault are displayed and a buzzer sounded to notify the user. This function is referred to as an alarm. This chapter explains the causes and remedial action of alarms and other faults.

Contact the place of purchase or ESPEC CORP. in the following cases.

- When the equipment fails operate normally after taking the prescribed remedial action.
- Where "Call service." is indicated in this chapter.

7.1 Faults indicated by alarm

When an alarm has been generated, take the following action.

- ① Check the alarm code indicated on the display.



AL06

- ② Take the remedial action prescribed for the alarm code in the Alarm code list.
- ③ Reset the alarm. Press the **POWER** key on the controller.
- ④ To reactivate the chamber, press the **POWER** key again.

• For alarms AL-1 and AL-9, steps ③ and ④ are unnecessary. The chamber will reset automatically just by clearing the alarm state. However, the display will remain unchanged after alarm AL-9, therefore press the **POWER** key to clear the display.

Table 7.1 Alarm code list

Alarm code	Location	Symptom	Probable cause	Remedial action
AL00	Burn out	Temperature sensor fault	Temperature sensor disconnection	Reconnect the temperature sensor.
AL01	Automatic temperature overheat	Temperature inside the chamber rose 10°C above the set temperature.	Specimens generated excessive heat.	Reduce specimen heat generation.
			Insufficient ventilation.	Open the damper.
			Temperature setting is too low.	Set temperature (ambient temperature + 20)°C
AL02	Upper temperature limit alarm	Temperature inside the chamber rose above the upper temperature limit alarm setting.	Upper temperature limit alarm setting is too low.	Change the upper temperature limit alarm setting.
			Specimens generated excessive heat.	Reduce specimen heat generation.
AL03	Lower temperature limit alarm	Temperature inside the chamber dropped below the lower temperature limit alarm setting.	Lower temperature limit alarm setting is too high.	Change the lower temperature limit alarm setting.
			Excessive ventilation.	Close the damper.
AL06	Overheat protector	The overheat protector tripped.	Overheat protector setting is too low.	Raise the overheat protector setting.
		(All digits of setting device display are flashing.)	Specimens generated excessive heat.	Reduce specimen heat generation.
		Trouble in the overheat protector temperature sensor ("---" burnout indication appears on setting device display.)	Faulty contact in overheat protector temperature sensor.	Reconnect the temperature sensor.
	Circuit protector	The circuit protector tripped.	Short circuit or overcurrent of the heating circuit.	Call service.
	Thermal fuse	The thermal fuse blew.	Heater system fault	Call service.
AL07	Electrical compartment temperature switch	The electrical compartment temperature switch tripped.	Electrical compartment cooling fan malfunction.	Call service.
	Air circulator overload relay	Air circulator overload relay tripped.	The air circulator shaft locked.	
	Belt blown detecting switch (Centrifugal switch)	Belt blown detecting switch tripped.	V-belt blown	Adjust or replace V-belt.
AL02	Time setting	The program is set to run at "0:00".	Inappropriate time setting.	Remake the setting.
	Temperature setting	The program (step) temperature setting exceeds the upper (lower) temperature limit alarm.	Inappropriate temperature setting.	Remake the setting.
E1	Memory error	Internal memory error	Internal memory error	Call service.
E2	Memory error	External memory error	External memory error	Call service.
2	CPU error	CPU malfunction	Malfunction caused by noise	Improve the power supply environment