

Compact Ultra Low Temperature Chamber MC-712R·812R





High performance and reliability come in a compact package, covers wide range of temperature testing needs, from ultra-low temperature -85°C to high temperature +180°C.

Thanks to N-Instrumentation, now it's available Ethernet connection, which allows you to control and monitor the chamber remotely, from a pc via web browser.

The new designed 36 percent larger square shape frost free window, made from multi layer glass with heater gives you superior visibility.

MC-812R



To minimize our chambers potential environmental impact R-449A is the best alternative to R-404A 64% Reduction R-404A R-449A *R-449A is available on request




Characteristics



Test area



USB memory port



Wide temperature range

Two models are available: a chamber with a temperature range from -85°C to +180°C and a chamber with a temperature range from -75°C to +100°C. They can be used for various purposes including temperature characteristic testing and low temperature storage testing.

Remote monitoring and control (Ethernet connection)

By adding optionally available "Ethernet Port (LAN Port)", you can connect the chamber to your local area network. By doing so, you can control and monitor the chamber from any computer on the network, using a web browser. You can program test patterns, start and stop the operation without you actually being at the site.

* This operation can only be performed when the power breaker is "ON"

Using sampling data

Sampling data (temperature set point and process value) can be copied via a USB memory device or recorded directly. It is also possible to copy program patterns between chambers without using a PC, enabling effective use of data.

* USB memory is not included.

Editing program patterns and displaying graphs

The program patterns registered in the test chamber can be edited via web browser and sampling data can be displayed as graphs.

Using the PC application software "Pattern Manager Lite"*, program patterns on a PC can be edited, displayed as graphs or output as CSV data even if offline.

*The Pattern Manager Lite software allows you to edit programs for your cabinet, view and edit data as graph, etc.

The software can be downloaded from the Test Navi website.

Controller

Tabbed user interface

Provides high resolution and fast display. Tabs at the bottom of the screen make it easy to activate any section.

Register test patterns

Up to 40 program operation setting with maximum of 99 steps and 3 constant operation settings can be registered.

Trend graph output

Trend graphs are displayed in the screen and recorded in the internal memory according to set conditions. Data can be also recorded directly onto USB memory for backup purposes. Measurement intervals and other conditions are capable to change.

Information

The information section shows information on the chamber status. Messages displayed according to operating timer inform you of maintenance checks. It is also possible to register and use additional notification items.

Supported languages

A simple operation changes display text to English or Russian.

Backtrace function

When the chamber stops because of trouble, the operation status just before the chamber stops is automatically recorded and saved. Saved data can be transferred by USB memory.

E-mail the data to ESPEC, and to be provided troubleshooting.







N-Instrumentation

Operating mode	Constant operation, program operation, Remote operation, stop		
Setting range	Constant setup 3 patterns Program setup 40 patterns (99 steps per program)		
Language	English, Russian (switch without restarting)		
External memory function	Interface USB 2.0 standard compliant (A-type connector) Supported functions Write log, Read/Write program (application software: Pattern Manager Lite), write backtrace Interface Ethernet port (100base-TX) Web application Monitor, setting operation, data collection, e-mail notification		
Web function (Optional)			

SPECIFICATIONS

Model			MC-712R	MC-812R	
System			Balanced Temperature Control system (BTC system)		
Performance *1	Temp. rang	ре	−75°C to +100°C	−85°C to +180°C	
	Temp. fluctuation		±0.5°C	±0.5°C: at -85°C to +100°C ±1.0°C: at +100.1°C to +180°C	
	Temp. gradient / Temp. variation in space		4.0°C	4.0°C: at -85°C to +100°C 8.0°C: at +100.1°C to +180°C	
	Temp. rate of change		Heat up rate: 7.0°C /min Pull down rate: 1.7°C /min	Heat up rate: 5.5°C /min Pull down rate: 2.2°C /min	
	Temp. extrachieveme		Heat up time: $+20^{\circ}\text{C} \rightarrow +100^{\circ}\text{C}$ 20 min Pull down time: $+20^{\circ}\text{C} \rightarrow -70^{\circ}\text{C}$ 60 min	Heat up time: $+20^{\circ}\text{C} \rightarrow +180^{\circ}\text{C}$ 30 min Pull down time: $+20^{\circ}\text{C} \rightarrow -80^{\circ}\text{C}$ 70 min	
Heater			Nichrome-strip wire heater 1 kW		
Cooler			Plate-fin cooler		
Refrigeration system		ystem	Mechanical cascade refrigeration system (air-cooled condenser)		
Refrigerator			Hermetically sealed compressor R-404A(R-449A is available on request), R-508A		
Expansion mechanism		chanism	Capillary tube system		
Fittings			Viewing window (W107×H120 mm with frost prevention heater), Cable port (ø50 mm×1), Power cable (about 3.0 m), Drain hose (1.5 m), USB memory port, Specimen power supply control terminal, RS-485 interface		
Capacity			64L		
Inside dimensions		ons	W400×H400×D400 mm		
Outside dimensions *3		sions *3	W900×H1200×D610 mm		
Weight			165kg		
Pov		200V AC 3ø 3W 50/60Hz	12A	14A	
	wer supply	220V AC 3ø 3W 60Hz	12A	14A	
		380V AC 3ø 4W 50Hz	8.3A	9.2A	
Allowable ambient conditions		ient conditions	0°C to +40°C		

^{*1} The performance values are based on IEC60068-3-5;2001, JTM K07;2007 for ambient temperature +23°C, related humidity 65%rh, rated voltage, and no specimen.

ACCESSORIES

Shelf (stainless)	2
Shelf brackets (stainless)	-2 sets
Cable port rubber plug (ø50 mm)	1
Chamber lamp	1
• Glass tube fuse 1 (250V AC 3A), 2 (250V	AC 5A)
Thermal fuse	1
Operation manual (CD)	1
Warranty card	1

Low GWP Refrigerant



R-449A is available on request.

SAFETY DEVICES

- · Leakage breaker for power supply (for 200/220V AC only) • Temperature switch for
- · Circuit breaker (for 380V AC only)
- · Control circuit short circuit protective fuse
- · System error
- Room temperature compensation burnout detection circuit.
- Dry bulb temperature burnout detection circuit
- Temperature switch for air circulator
- Thermal fuse
- · Refrigerator overload relay
- · SSR overload & short circuit protecting circuit breaker

- · Reverse prevention relay
- compressor
- Refrigerator automatic delay circuit (built inside temperature controller)
- · Absolute upper/lower temperature limit alarm (with built-in temperature controller)
- Overheat protector
- Temperature upper limit deviation alarm
- · Specimen power supply control terminal
- Electrical compartment door switch

^{*2} Temperature extreme achievement time accuracy is within Max. +10% due to power frequency change.

^{*3} Excluding protrusions.

OPTIONS

Power cable

Select one instead of the standard 3 m cable.

- 5 m
- 10 m
- * Excluding 380V AC.

Additional cable port

Provided in addition / replacement of the standard cable port (left side, ø50 mm). Available location:

- Left side
- Ceiling

Available dimensions:

- ø25 mm
- ø50 mm
- ø100 mm
- * Comes with a rubber plug and a cap.



Cable port rubber plug

Prevents air leakage from the cable port.

• 50 mm

Shelf / Shelf bracket

Equivalent to standard accessory.



Shelf

Web function Ethernet port

It is an embedded server solution that allows monitoring and programming chamber via any computer, tablet computer, or other terminal.

I/O Interface

Communication ports to connect the chamber to a PC.

- RS-232C
- GPIB

Communication cables

 \bullet RS-485 $$ 5 m / 10 m / 30 m

• GPIB 2 m / 4 m

Paperless recorder

A temperature recorder that utilizes a liquid-crystal display fitted with a touch-panel.

Display: 5.7inch color touch panel Scan interval: 5 sec (default) Internal recording media:

Flash memory 8MB

External recording media:

CF memory card (Supplies with a 256 MB CF card) USB flash drive

< Temperature type > No. of input channel:

Temperature 1

(5 more channels can be turned ON)



Recorder

- RJ23 6 dots -100°C to +100°C
- RJ25 6 dots -100°C to +200°C

Temperature recorder wiring

Preparation of a power cable, temperature sensor and a grounding wire for recorder installation in the future.

Thermocouple

For measuring specimen temperature Thermocouple type T (Copper/Copper-Nickel)

- 2 m
- 4 m
- 6 m

Alarm output terminal

If the safety device of the chamber is activated, external alarm terminal will notify it to a remote point.

Emergency stop pushbutton

Stops the chamber immediately.

* Excluding 380V AC.

Caster

Installed for mobility.

4 casters, with leveling feet



Safety precautions

- Do not use specimens which are explosive or flammable, or which contain similar substances. To do so could be hazardous, as this may lead to fire or explosion.
- Do not place corrosive substances in the chamber. If corrosive substances are generated by the specimen, the life of the chamber may be significantly shortened specifically because of the corrosion of stainless steel and copper and because of the deterioration of resin and silicon.
- Do not place living beings or substances that exceed allowable heat generation.
- Be sure to read the user's manual before operation.

ESPEC CORP. https://www.espec.co.jp/english

3-5-6, Tenjinbashi, Kita-ku, Osaka 530-8550, Japan Tel: 81-6-6358-4741 Fax: 81-6-6358-5500

ESPEC NORTH AMERICA, INC.

Tel: 1-616-896-6100 Fax: 1-616-896-6150

ESPEC EUROPE GmbH

Tel: 49-211-361850-0

ESPEC ENVIRONMENTAL CHAMBERS SALES AND ENGINEERING LTD. STI. (Turkey)

Tel: 90-212-438-1841 Fax: 90-212-438-1871

ESPEC ENVIRONMENTAL EQUIPMENT (SHANGHAI) CO., LTD.

Head Office

Tel:86-21-51036677 Fax:86-21-63372237 **BEIJING Branch** Tel: 86-10-64627025 Fax: 86-10-64627036

GUANGZHOU Branch

Tel:86-20-83317826 Fax:86-20-83317825

SHENZHEN Branch

Tel:86-755-83674422 Fax:86-755-83674228

SUZHOU Branch

Tel:86-512-68028890 Fax:86-512-68028860

TIANJIN Branch

Tel: 86-22-26210366 Fax: 86-22-26282186

XI'AN Branch

Tel: 86-29-88312908 Fax: 86-29-88455957

CHENGDU Branch

Tel:86-28-88457756 Fax:86-28-88474456

WUXI Branch

Tel:86-510-82735036 Fax:86-510-82735039

ESPEC TEST TECHNOLOGY (SHANGHAI) CO., LTD.

Tel:86-21-68798008 Fax:86-21-68798088

ESPEC ENGINEERING (THAILAND) CO., LTD.

Tel: 66-3-810-9353 Fax: 66-3-810-9356

ESPEC ENGINEERING VIETNAM CO., LTD.

Tel:84-24-22208811 Fax:84-24-22208822

ISO 9001 (JIS Q 9001)

Quality Management System Assessed and Registered

ESPEC CORP. has been assessed by and registered in the Quality Management System based on the International Standard ISO 9001:2015 (JIS Q 9001:2015) through the JSA Solutions Co.,Ltd.

* The organization of these certificates is ESPEC CORP. Japan.







ISO 27001 (JIS Q 27001)

ISO 14001 (JIS Q 14001)

Quality Management System Assessed and Registered

* The organization of these certificates is ESPEC CORP. Japan.



ISMS





MS CM021



- **Environmental Management System Assessed** and Registered
- * The organization of these certificates is ESPEC Group Japan.
- •Specifications are subject to change without notice due to design improvements.
- Corporate names and trade names mentioned in this catalog are trademarks or registered trademarks.